# **Student Information**

Full Name: Mehmet Rüchan Yavuzdemir

Id Number: 2522159

# 1 Ethernet

Figure 1: Answer 1-2-3

### Answer 1

48-bit Ethernet source address is c4:41:1e:75:b1:52.

### Answer 2

48-bit Ethernet destination address is 00:1e:c1:7e:d9:01. However, this address is not the server's Ethernet address, it is the Ethernet address of the router 3ComEurope, responsible for forwarding the sent packet to its final destination.

### Answer 3

The Type field of the frame carrying the HTTP GET request is 0x0800 in hexadecimal notation, which corresponds to the upper layer IPv4.

```
00 1e c1 7e d9 01 c4 41
0000
                                 1e 75 b1 52 08 00 45 02
                                                             ---~--A -u-R--E-
      02 97 00 00 40 00 40
                            06
                                 4b 21
                                       80 77
                                             f7
                                                42 80
                                                       77
                                                                -a-a-K!-w-B-w
      f5 0c d3 1a 00 50 df c1
                                 db 19 56 32 7b c7 80 18
                                                                --P----V2{---
0030
      08 0a 98 99
                   00
                      00 01
                            01
                                 08 0a 08 e7 51
                                                ba f7 d2
                                                                . . . . . . . . . 0 . . .
0040
      96 a8 47 45
                  54 20
                         2f
                                 69 72
                                       65
                                          73 68
                                                61 72
                                                       6b
                                                               GET /w ireshark
                                                             -labs/HT TP-wires
0050
      2d 6c 61 62
                  73 2f 48 54
                                 54 50
                                       2d
                                          77 69
                                                72 65
      68 61 72 6b 2d 6c 61 62
                                 2d 66 69 6c 65 33 2e 68
                                                             hark-lab -file3.h
0060
```

Figure 2: Answer 4

### Answer 4

There are no preamble bits in the .pcap file, the Ethernet frame directly starts with the Ethernet destination address. There are 14 bytes reserved for the Ethernet header, 20 bytes for the IP header, and 32 bytes for the TCP header. Hence, there is a total of 14 + 20 + 32 = 66 bytes until the 'G' letter of the HTTP 'GET'.

Figure 3: Answer 5-6-7

48-bit Ethernet source address is 00:1e:c1:7e:d9:01. However, this address is not the server's Ethernet address, it is the Ethernet address of the router 3ComEurope, responsible for forwarding the sent packet to the possibly other routers.

#### Answer 6

48-bit Ethernet destination address is c4:41:1e:75:b1:52. Yes, it is the Ethernet address of the sender.

### Answer 7

The Type field of the frame carrying the HTTP GET request is 0x0800 in hexadecimal notation, which corresponds to the upper layer IPv4.

```
0000
      48 54 54 50 2f 31 2e 31
                                20 32 30 30 20
                                                      0d
                                                            HTTP/1.1
                                                                      200 OK
                                                4f 4b
                                                            Date: T ue, 02 N
0010
      0a 44 61 74 65 3a 20
                            54
                                75 65 2c 20
                                            30
                                                32 20
                                                      4e
0020
         76 20
               32
                  30 32 31
                            20
                                31 37 3a 33 37
                                                3a 34 33
                                                            ov 2021
                                                                     17:37:43
      20 47 4d 54
                  0d 0a 53
                            65
                                72 76 65 72 3a
                                               20 41 70
                                                             GMT Se rver: Ap
0030
0040
      61 63 68
               65
                  2f 32 2e
                           34
                                2e 36
                                      20 28 43
                                                65 6e 74
                                                            ache/2.4 .6 (Cent
         53 29
               20
                  4f
                     70 65
                                53 53
                                      4c 2f 31 2e 30 2e
                                                            OS) Open SSL/1.0.
0050
                            6e
0060
      32 6b 2d 66 69 70 73 20
                                50 48 50 2f 37 2e 34 2e
                                                            2k-fips
                                                                     PHP/7.4.
0070
      32 35 20 6d 6f 64 5f 70
                                65 72 6c 2f 32 2e 30 2e
                                                            25 mod p erl/2.0.
```

Figure 4: Answer 8

#### Answer 8

The header bits are exactly as is in Figure 4. The frame containing the Ethernet, IP, and TCP header information does not contain an HTTP OK message, it is segmented. Still, since we assume a frame starting with an Ethernet frame begins with the Ethernet frame's destination address, that's fine. 'HTTP/1.1 200' takes 13 bytes, as shown in the figure. Hence, there is a total of 14 + 20 + 32 = 66 bytes until 'HTTP/1.1 200', and there are 66 + 13 = 79 bytes until the 'O' letter of the HTTP/1.1 200'.

```
    [4 Reassembled TCP Segments (4861 bytes): #131(1448), #132(1448), #133(1448), #134(517)]
        [Frame: 131, payload: 0-1447 (1448 bytes)]
        [Frame: 132, payload: 1448-2895 (1448 bytes)]
        [Frame: 133, payload: 2896-4343 (1448 bytes)]
        [Frame: 134, payload: 4344-4860 (517 bytes)]
        [Segment count: 4]
        [Reassembled TCP length: 4861]
        [Reassembled TCP Data [truncated]: 485454502f312e3120323030204f4b0d0a446174653a205475652
```

Figure 5: Answer 9

As shown in the figure above, 4 Ethernet frames carry the complete data of the HTTP OK 200 response message.

# 2 The Address Resolution Protocol




Figure 6: Answer 10-11-12

# Answer 10

The hexadecimal value of the source address in the Ethernet frame containing the ARP request message is c4:41:1e:75:b1:52.

### Answer 11

The hexadecimal value of the destination address in the Ethernet frame containing the ARP request message is ff:ff:ff:ff:ff; which is the broadcast MAC address. Hence, there is no specific device to be sent, all the machines on the Local Area Network (LAN) receive this request message.

### Answer 12

The Type field of the frame carrying the ARP messages is 0x0806 in hexadecimal notation, which corresponds to the upper layer ARP.

Figure 7: Answer 13-14-15

The Ethernet header is 14 bytes, ARP hardware, and protocol type is 2 bytes each, and hardware and protocol size is 1 byte each. Hence, there is 14 + 2 + 2 + 1 + 1 = 20 bytes from the very beginning of the Ethernet frame until ARP opcode field begins.

# Answer 14

Yes, it does. The IP address of the sender is 128.119.247.66.

# Answer 15

Since the ARP request message is broadcasted, the target IP address, which is the IP address of the gateway router within the same subnet is 128.119.247.1.




Figure 8: Answer 16-17-18

The value of the opcode field in the ARP reply message is 2.

# Answer 17

By looking at the ARP response message in Figure 8 above, the Ethernet address of the IP address specified in the ARP request message is the Ethernet source address, which is 00:1e:c1:7e:d9:01.

# Answer 18

The ARP request is broadcast, however, the ARP response message is specifically sent to the sender's Ethernet address. Hence, we cannot see other response messages being sent to the other devices.